



CT-08 YARD KIT 6 TOOLS

INSTALL GUIDE 41

Installation tools for Standard Profile Range of clips. One each CT-01, CT-03, CT-05, CT-07, CT-09, and CT-10 in plastic box.



CT-01 DRILL 10MM WITH SHOULDER

Use with Standard Profile Range and Low Profile Range. For drilling through panel and pilot hole for CT-07.



CT-03 INSTALL TOOL FOR PC-F1A

Use with Standard Profile Range. For installation of self tapping female PC-F1A, using battery drill with correct torque setting.



CT-05 PANEL REMOVAL TOOL

Stainless steel tool for removing covered (upholstered) panels. Do not use with painted panels.



CT-07 STEP DRILL (TUNGSTEN)

Use with Standard Profile Range for PC-F1A, 16.8mm diameter tungsten tipped to drill out 10mm hole in frame. See install guides and video for correct use.



CT-09 PANEL DRILL 10MM FORSTNER TYPE

Use with Standard Profile, Low Profile and Maxi Metal Range. To drill blind holes in the back of panels. See install guides and videos



CT-10 INSTALL TOOL SELF TAPPING MALE CLIPS

Use with Standard Profile, Low Profile, and Panel Control Range. For installation of self tapping male PC-M1A, PC-M2H, PC-VM1, PS-150, and LP-M8, using battery drill with correct torque setting.