



892 AC Z2 80 26



Icons: Worker, Warning, Fall, and Document. www.camar.it/warning

Fe

100 12000 500



893 AS Z1 80 10



Icons: Worker, Warning, Fall, and Document. www.camar.it/warning

10 Fe

200 7200 400

