




Sistemi esterni di protezione External systems for protection


Accessori Accessories Serie 10
Serie 20
Serie 90



Adatto a realizzare angoli esterni con
apertura compresa tra 90° e 135°.
Suitable for external corners with spread
between 90° and 135°.


Multiangolo 90°
Multicorner 90°

Code	mm	pcs
21/195T	80	200
21/1950	100	200
21/1952	120	200
21/1953	130	200
21/1954	140	200
21/1955	150	200
21/1957	170	200
21/1958	180	200




Angolo 90°
Corner 90°

Code	mm	pcs
21/19FT	80	200
21/19F0	100	200
21/19F2	120	200
21/19F3	130	200
21/19F4	140	200
21/19F5	150	200
21/19F7	170	200
21/19F8	180	200



Angolo Jolly
Jolly corner

Code	mm	pcs
21/19.HT	80	100
21/19.H0	100	100
21/19.H2	120	100
21/19.H3	130	100
21/19.H4	140	100
21/19.H5	150	100
21/19.H7	170	100
21/19.H8	180	200




Angolo 135°
Corner 135°

Code	mm	pcs
21/19GT	80	200
21/19G0	100	200
21/19G2	120	200
21/19G3	130	200
21/19G4	140	200
21/19G5	150	200
21/19G7	170	200
21/19G8	180	200

77



Accessori Accessories Serie 10
Serie 20
Serie 90




Terminale
Terminal

Code	mm	pcs
21/194T	80	200
21/1940	100	200
21/1942	120	200
21/1943	130	200
21/1944	140	200
21/1945	150	200
21/1947	170	200
21/1948	180	200



Giunzione
Joint

Code	mm	pcs
21/192T	80	200
21/1920	100	200
21/1922	120	200
21/1923	130	200
21/1924	140	200
21/1925	150	200
21/1927	170	200
21/1928	180	200



Terminale Easy Fit
Easy Fit terminal

Code	mm	pcs
21/19MT	80	200
21/19M0	100	200
21/19M2	120	200
21/19M4	140	200
21/19M5	150	200
21/19M7	170	200
21/19M8	180	200