




VOLPATO
Be part of [...]


Accessori Accessories >

Serie 3T 30-32-35-36-38-3A AL
30-32-34-35-38 CR
30-32-35-38 MR




Code	mm	pcs
21/095T.AL	80	100
21/0950.AL	100	100
21/0952.AL	120	100
21/0954.AL	140	100
21/0955.AL	150	100
21/0956.AL	160	100
21/0958.AL	180	100
21/095A.AL	200	100

Multiangolo
Multicorner




Code	mm	pcs
21/091T.AL	80	100
21/0910.AL	100	100
21/0912.AL	120	100
21/0914.AL	140	100
21/0915.AL	150	100
21/0916.AL	160	100
21/0918.AL	180	100
21/091A.AL	200	100

Angolo 90° A1
Corner 90° A1



Code	H mm	pcs
21/093T.AL	80	100
21/0930.AL	100	100
21/0932.AL	120	100
21/0934.AL	140	100
21/0935.AL	150	100
21/0936.AL	160	100
21/0938.AL	180	100
21/093A.AL	200	100

Angolo 135° A3
Corner 135° A3



Code	H mm	pcs
21/09CT.AL	80	100
21/09C0.AL	100	100
21/09C2.AL	120	100
21/09C4.AL	140	100
21/09C5.AL	150	100
21/09C6.AL	160	100
21/09C8.AL	180	100
21/09CA.AL	200	100

Angolo 90° AC
Corner 90° AC




Code	H mm	pcs
21/09BT.AL	80	100
21/09B0.AL	100	100
21/09B2.AL	120	100
21/09B4.AL	140	100
21/09B5.AL	150	100
21/09B6.AL	160	100
21/09B8.AL	180	100
21/09BA.AL	200	100

Angolo 135° AB
Corner 135° AB




Code	H mm	pcs
21/092T.AL	80	100
21/0920.AL	100	100
21/0922.AL	120	100
21/0924.AL	140	100
21/0925.AL	150	100
21/0926.AL	160	100
21/0928.AL	180	100
21/092A.AL	200	100

Giunzione
joint



Code	mm	pcs
21/29MT.AL	80	100
21/29M0.AL	100	100
21/29M2.AL	120	100
21/29M4.AL	140	100
21/29M5.AL	150	100
21/29M6.AL	160	100
21/29M8.AL	180	100
21/29MA.AL	200	100

Terminale Easy Fit
Easy Fit terminal
Pag.74



Code	mm	pcs
21/29JT.AL	80	100
21/29J0.AL	100	100
21/29J2.AL	120	100
21/29J4.AL	140	100
21/29J5.AL	150	100
21/29J6.AL	160	100
21/29J8.AL	180	100
21/29JA.AL	200	100

Joint Easy Fit
Easy Fit Joint
Pag.74